3M

Instructions and Parts List

3M-Matic[™]

800asb

Type 29600

Adjustable

Case Sealer

with

AccuGlide II
STD 1-1/2 Inch
Taping Heads

Serial No. _____

For reference, record machine serial number here.



Important Safety Information

Read "Important Safeguards", pages 3-5 and also operating "Warnings", page 16
BEFORE INSTALLING OR OPERATING THIS EQUIPMENT.

Spare Parts

It is recommended you immediately order the spare parts listed on page 35. These parts are expected to wear through normal use and should be kept on hand to minimize production delays.

To Our Customers:

This is the 3M-Matic[™]/AccuGlide[™]/Scotch[™] brand equipment you ordered. It has been set up and tested in the factory with "Scotch" brand tapes. If technical assistance or replacement parts are needed, call or Fax the appropriate number listed below.

Included with each machine is an Instructions and Parts List manual.

Technical Assistance:

3M-Matic[™] Helpline – 1-800/328 1390. Please provide the customer support coordinator with the machine number, machine type/model and serial number. If you have a technical question that does not require an immediate response, you may Fax it to 715/381 0248.

Replacement Parts and Additional Manuals

Order parts by part number, part description and quantity required. Also, when ordering parts and/or additional manuals, include machine name, number and type. A parts order form is provided at the back of this manual.

3M/Tape Dispenser Parts
241 Venture Drive 1-800/344 9883
Amery, WI 54001-1325 FAX# 715/268 8153

Minimum billing on parts orders will be \$25.00. Replacement part prices available on request. \$10.00 restocking charge per invoice on returned parts.

Note: Outside the U.S., contact the local 3M subsidiary for parts ordering information.



To Our Customers:

This is the 3M-Matic[™]/AccuGlide[™]/Scotch[™] brand equipment you ordered. It has been set up and tested in the factory with "Scotch" brand tapes. If any problems occur when operating this equipment, and you desire a service call, or phone consultation, call, write or Fax the appropriate number listed below.

Included with each machine is an Instructions and Parts List manual.							
	CE, REPLACI	EMENT PART	S AND ADDIT	TIONAL MANU	JALS		

Order parts by part number, part description and quantity required. Also, when ordering parts and/or additional manuals, include machine name, number and type.



Instruction Manual

800asb, Type 29600 Adjustable Case Sealer

This instruction manual is divided into two sections as follows:

Section I	Includes all information related to installation, operation and parts for the case sealer.
Section II	Includes specific information regarding the AccuGlide™ II STD 1-1/2 Inch Taping Heads

Table of Contents	Page
Section I – 800asb Adjustable Case Sealer	
Description	1
Equipment Warranty and Limited Remedy	2
800asb Contents	2
Important Safeguards	3 - 5
Specifications	7 - 9
Installation and Set-Up	11 - 13 11 11 - 13 11 - 12 12 12 13 13 13
Operation	15 - 19 16 16 16 17 - 18 19
Maintenance Cleaning Lubrication Circuit Breaker Knife Replacement, Taping Head Drive Belts Replacement/Tension Adjustment	21 - 23 21 21 22 22 22 - 23 22 - 23

Table of Contents (Continued)		
Adjustments	25	
Drive Belt Tension	25	
Taping Head Adjustments	25	
Special Set-Up Procedure	27 - 31	
Drive Belt Height	27	
Disassemble	27	
Reassemble	27	
Changing Tape Leg Length	28	
Box Height Range	28 - 31	
Troubleshooting	33	
Troubleshooting Guide	33	
Electrical Diagram	34	
Spare Parts/Tools		
Options/Acessories	35	
Replacement Parts Illustrations and Parts Lists	36 - 73	

Section II – AccuGlide $^{\text{TM}}$ II STD 1-1/2 Inch Taping Heads